



# Installation Guide

WARNING THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLIANCE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

### **Items List:**

- · Vapor Tight Fixture with Lens & 5-6 ft. power cable
- · 2 Mounting Brackets
  - Alluminum or Stainless Steel
- · Sensor Manual (If package includes occupancy sensor accessory)
- · 5-6ft Control Cable (If package includes occupancy sensor accessory)

### Instructions

- 1.) Read all warnings in this guide and on the fixture itself before attempting installation.
- 2.) Install fixture in accordance with the local electrical code.
- 3.) Programming Sensor Manual included to allow modifications to the sensor perameters.

## **Electrical Information**

MODEL	INPUT VOLTAGE (VAC)	FREQUENCY (HZ)	INPUT CURRENT Max. (A)	INPUT POWER
DRA-34-4	120-240 277 VAC	50/60	0.28	34

### Wiring:

Power cable is nominally 5-6 ft. long, with flying leads (black-AC, white-Neutral, green-Ground).

Control cable 2 conductor comes with flying leads (0-10V Output, Red 0-10 V Power & Black SIGNAL GROUND RETURN (dims other lights from single sensor).



Wiring Identifier - Power Cable		
Flying Leads	Function	
BLACK (AC out)	Live	
WHITE (AC out)	Neutral	
GREEN	Ground	

Wiring Identifier - Sensor			
Flying Leads	Function		
BLACK (AC out)	0-10 V Power		
RED (AC out)	Signal Ground Return		